



Installation

Preparation:

Clean surfaces so they are free from oil, grease, old coverings, rust and adhesives. All foreign substances should be removed. Any painting or refinishing of the surface should be done prior to installation of the step covers. The surface must be structurally sound and dry prior to installation. The fiberglass step cover and nosing is not a weight bearing material. Cracks, worn areas, depressions, holes, etc must be repaired.

Materials Required:

- Personal Protection Equipment such as Safety Glasses, Dust Mask, Gloves, Ear Protection, Protective Clothing.
- Marking tools such as a marker, pen, pencil
- Shop type Rags
- Drill with appropriate bit – carbide bit suggested
- Tape Measure / Ruler
- Sandpaper
- Chalk Line
- Vacuum or Broom & Dust Pan
- Adhesive / Sealant
- Fasteners (see below)



Fastener:

SUBSTRATE	FASTENER RECOMMENDED
Wood	Stainless Steel
Concrete	Masonry Screw with anchor if needed
Steel	Stainless Steel